


BT400GII

Bluetooth Headset

Quick Start-Up

www.bluetake.com


- Overview of BT400G II -



- “Volume Up” button
- “Volume Down” button
- “Power/Talk/Pairing” button




Open / Close the microphone

The microphone can be closed when the headset doesn't use.



- DC POWER IN
- Earhook
- Speaker
- Microphone

- Changing the earhook -






The BT400GII Bluetooth headset can be worn on either ear. Please carry out the following steps to shift the earhook for wearing it on the other ear.

1. Carefully remove the earhook from the headset
2. Change the direction of the earhook as shown in diagram 2.
3. Carefully replace the earhook on the headset.



- Turning the headset ON/OFF -

To turn your headset ON:

Press and hold the  button for **3** seconds, and then the speaker will emit two high tones. When the power is on, the LED in the  button starts to flash blue.

(Note: The headset will go to pairing mode if you press and hold the  button for **5** seconds from OFF status)

To turn your headset OFF:



Press and hold the  button for **3** seconds, and then the speaker will emit two high tones. When the power is off, the LED in the  button stops flashing.

- Charging the battery -

Before using BT400GII you will have to charge the battery for approximate 3 hours to ensure a fully charged battery.

DC POWER IN



1. Plug the AC power adapter into the DC POWER IN socket situated at the back of the headset.
2. Plug the AC power adapter's plug into an electrical wall outlet.
3. When charging, the LED in the  button is on and remains lit.
4. The LED in the  button turns to be green after the battery is fully charged.
5. Remove the AC adapter from the headset's AC power jack.

Caution : Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.



Notice : The headset doesn't work while it's charging.

- Pairing to a Bluetooth phone -

What is Bluetooth pairing?

Before using your headset for the first time, you must pair it with a particular Bluetooth cell phone previously. "Pairing" process creates a unique wireless link between two devices. Once paired, the communication between two devices do not need any authentication or authorization anymore.


Please follow the instruction below to pair the headset with a Bluetooth cell phone:

1. Ensure the headset is OFF.
2. Press and hold the  button for approximately **5** seconds until the headset LED starts to flash with blue and red.
3. Release the  button when the LED is flashing, the status indicates that the headset is in pairing mode and waiting to pair with another Bluetooth device.
4. Follow the operating instructions for your Bluetooth phone to start a pairing process.

5. Your phone's display will indicate that it found one or more Bluetooth devices, the "**Bluetake Headset**" should be included in the list, please select it for pairing.
6. The phone's display then prompt you for a pairing passkey or PIN, please enter four zeros "**0000**".
7. When the pairing process is finished successfully, the headset LED will return to normal status of flashing blue only.
8. Your phone's display may ask you whether you want to change the headset's name, you can replace the "Bluetake Headset" with any you may prefer.

- Answering/Ending a call -

Answering a call.

After being paired with your cell phone, the headset is now ready to receive incoming calls without handling the phone. When there's an incoming call, both the cell phone and the headset will ring simultaneously. Upon hearing the ring tones through the headset's speaker you can answer the incoming call by pressing  button and then speaking normally.

Ending a call.

You can use either of the ways to end a call:

1. Press the headset's  button to end a call.
2. Press the phone's keypad to end a call.

- Making a call -

There are two ways to make calls:

1. Using the phone's keypad:

As general usage, dial the phone number you want to call by pressing the phone's keypad. You may also hear the dialing tones through the headset.


2. Using the **Voice Dialing** through the headset:

What is voice dialing?

Voice dialing is a feature on some Bluetooth phones which allows you make calls by saying the name of the person you want to call. The phone compares your voice with your previous recording (called a voice tag). If they match then the phone will automatically dial the corresponding phone number. Not all Bluetooth phones support voice dialing, please refer to your phone's spec to make sure whether your phone supports this feature.











The headset does not have a keyboard so it's necessary to use voice dialing to make calls. To do this you have to record voice tags for the contacts in your phone address book.

If your phone supports voice dialing function, you can use this feature with the headset easily. *Note that the voice dialing on your phone must be enabled and the voice tags must have been recorded previously.* (Please refer to your phone's instruction on recording and storing voice tags)

- a. Briefly press the  button once.
- b. After the tone, say the name of the person you want to call.
- c. The phone number will be dialed automatically by phone after recognizing the correct voice tag.

- Appendix I -

Button Function

 button	Turn ON/OFF	Press the  button for 3 seconds until the blue LED flashes five times.
	Answer/End calls	Press the  button once
	Pairing	When the headset is off, press the  button to turn on and keep it pressed for about 5 seconds until the LED flashes blue and red alternately.
 /  button	Volume control	Press the  or  button repeatedly until you reach your desired level.
	Mute / Unmute	Press the  or  button for about 2 seconds.

- Appendix II -

Audio Tone

Turn On	Two high tones
Turn Off	Two low tones
Pairing mode	Two high tones
Incoming call	A ring tone at 2 seconds interval
Mute	Repeated two low beeps at a 3 seconds interval
Unmute	A single beep
Battery low	Starts when the talk time is left about 3~5 minutes. At a 16 seconds interval.

FCC INFORMATION

The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraph:

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user should not modify or change this equipment without written approval from **Bluetake Technology Co., Ltd.** Modification could void authority to use this equipment.